



AirTite F-2 Series

FRL PSI	<i>Torque-Ft. lbs</i>											
	AT800F-2		AT1200F-2		AT2650F-2		AT3700F-2		AT3700F-2		AT5800F-2	
	1st Gear	2nd Gear	1st Gear	2nd Gear	1st Gear	2nd Gear	1st Gear	2nd Gear	1st Gear	2nd Gear	1st Gear	2nd Gear
20	280	89	406	125	904	284	1268	398	1268	396	1973	620
25	319	101	462	196	1022	323	1444	453	1444	451	2246	706
30	359	112	518	231	1139	363	1619	508	1619	506	2520	792
35	398	124	574	249	1257	402	1795	563	1795	562	2793	878
40	437	136	630	266	1375	441	1971	618	1971	617	3067	963
45	476	147	686	284	1493	480	2147	673	2147	672	3340	1049
50	516	159	742	301	1610	520	2322	728	2322	727	3614	1135
55	555	171	799	319	1728	559	2498	784	2498	783	3887	1221
60	594	182	855	337	1846	598	2674	839	2674	838	4160	1307
65	634	194	911	354	1963	638	2849	894	2849	893	4434	1393
70	673	205	967	372	2081	677	3025	949	3025	948	4707	1479
75	712	217	1023	390	2199	716	3201	1004	3201	1003	4981	1564
80	751	229	1079	407	2317	755	3377	1059	3377	1059	5254	1650
85	791	240	1135	425	2434	795	3552	1114	3552	1114	5528	1736
90	830	252	1191	372	2552	834	3728	1169	3728	1169	5801	1822

(281) 796-1516

www.empiretorquetools.com