



AirTite F-2 Series										
FRL PSI	<i>Torque-Ft. lbs</i>									
	AT7000F-2		AT8000F-2		AT12500F-2		AT25000F-2		AT35000F-2	
	1st Gear	2nd Gear	1st Gear	2nd Gear	1st Gear	2nd Gear	1st Gear	2nd Gear	1st Gear	2nd Gear
20	2369	745	2762	867	4279	1180	8482	2434	11801	3497
25	2697	837	3145	1347	4869	1349	9667	2771	13518	3980
30	3025	930	3528	1587	5459	1517	10853	3108	15236	4462
35	3353	1022	3910	1708	6049	1686	12038	3445	16953	4945
40	3680	1115	4293	1828	6639	1854	13223	3783	18671	5427
45	4008	1207	4676	1948	7229	2023	14409	4120	20388	5910
50	4336	1300	5059	2068	7819	2191	15594	4457	22106	6392
55	4664	1392	5442	2188	8409	2360	16780	4794	23823	6875
60	4992	1484	5824	2308	8999	2529	17965	5131	25540	7357
65	5320	1577	6207	2428	9589	2697	19150	5468	27258	7840
70	5648	1669	6590	2548	10179	2866	20336	5805	28975	8322
75	5975	1762	6973	2668	10769	3034	21521	6143	30693	8805
80	6303	1854	7355	2788	11359	3203	22706	6480	32410	9287
85	6631	1947	7738	2908	11949	3371	23892	6817	34128	9770
90	6959	2039	8121	2548	12539	3540	25077	7154	35845	10252

(281) 796-1516

[www.empiretorquetools.com](http://www.empiretorquetools.com)