



### AirTite R Series Conversion Chart

Pump PSI	<i>Torque-Ft. lbs</i>					
	AT2000R	AT2550R	AT3200R	AT4500R	AT7000R	AT8000R
20	671	870	1099	1534	2408	2810
25	763	990	1251	1747	2742	3199
30	855	1110	1404	1959	3075	3588
35	947	1230	1556	2172	3409	3977
40	1039	1351	1708	2384	3742	4366
45	1131	1471	1860	2597	4076	4755
50	1223	1591	2013	2809	4409	5144
55	1315	1711	2165	3022	4743	5534
60	1407	1831	2317	3235	5076	5923
65	1499	1951	2470	3447	5410	6312
70	1591	2071	2622	3660	5743	6701
75	1683	2192	2774	3872	6077	7090
80	1775	2312	2926	4085	6410	7479
85	1867	2432	3079	4297	6744	7868
90	1959	2552	3231	4510	7077	8257

(281) 796-1516

[www.empiretorquetools.com](http://www.empiretorquetools.com)